



Official Lane Maintenance and Capital Equipment Provider



Select Machine

### Pattern Information

Date: 1-Dec-12

Pattern Type: Competitive

Pattern Difficulty: Medium

Pattern Designer: BRUNSWICK

Pattern Volume (ml): 22.47

### Pattern Parameters

Pattern Number: 5

Pattern Name: INFERNO

Mode: Clean & Oil

Forward Speed: Max Clean

Start Cleaner Spray: 0

Start Squeegee: 0

Start Oiling: 6

Split Pattern: No

### Supplies Information

Lane Cleaner: \_\_\_\_\_

Cleaner Mixture Ratio: : 1

Cleaner Transition Distance: 41 Authority22

Cleaner Spray End Distance: 53 Envoy

Lane Conditioner: \_\_\_\_\_

### Surface Information

Surface Type: \_\_\_\_\_

Surface Brand: \_\_\_\_\_

Age: \_\_\_\_\_

Notes: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5	Zone 6	Zone 7	Zone 8
Zone End Distance	8	16	22	27	32	39		
Zone Ratio	L 2.5 : 1	4.1 : 1	4.2 : 1	4.0 : 1	4.3 : 1	### : 1	### : 1	### : 1
	R 2.5 : 1	4.1 : 1	4.2 : 1	4.0 : 1	4.3 : 1	### : 1	### : 1	### : 1
Zone Volume (ml)	8.22	6.50	3.84	2.21	1.70	0.00	0.00	0.00

ZONE	7 Pin Side																	Board Number												10 Pin Side										
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1	
1	25	25	25	25	25	30	60	65	73	73	81	81	85	85	85	85	85	85	85	85	85	85	85	85	85	85	85	81	81	73	73	65	60	30	25	25	25	25	25	
2	18	18	18	18	18	18	18	23	55	66	66	71	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	71	66	66	55	23	18	18	18	18	18	18	18	18
3	14	14	14	14	14	14	14	16	43	51	51	55	60	60	60	60	60	60	60	60	60	60	60	60	60	60	55	51	51	43	16	14	14	14	14	14	14	14	14	
4	11	11	11	11	11	11	11	11	11	13	35	42	45	45	45	45	45	45	45	45	45	45	45	45	45	45	45	42	35	13	11	11	11	11	11	11	11	11	11	
5	8	8	8	8	8	8	8	8	8	8	10	27	33	35	35	35	35	35	35	35	35	35	35	35	35	35	35	33	27	10	8	8	8	8	8	8	8	8		
6	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
7																																								
8																																								

